



the.artceram



Installation & Service Manual

Manuale di installazione e manutenzione

Montaj ve Servis Kılavuzu


Installations- und Servicehandbuch

Manuel d'installation et d'entretien

Manual de instalación y mantenimiento






Руководство по установке и обслуживанию

دليل التركيب والصيانة






0 - 100 cm



10 mm



15 mm



















17 mm





19 mm



23 mm



PRO-D










min

max







Do not detach the access channel
If you need to remove the access channel, make sure that attaching is done correctly again

the.artceram









PRECOMBIBOGE.net






PRO-D









PRO-D






PRO-D











PRO-D












PRO-D












PRO-D











PRO-D












PRO-D



PRO-D





PRO-D




* Do not remove the cover before installing the actuator panel

- * Kapağı aktuatör paneli montajından önce sökmeyin
 - * Entfernen Sie nicht die Abdeckung, bevor Sie die Antriebsplatte installieren
 - * Ne retirez pas le couvercle avant d'installer le panneau de l'actionneur
 - * Non rimuovere il coperchio prima di aver installato il pannello dell'attuatore
 - * No retire la cubierta antes de instalar el panel del actuador
 - * Не снимайте крышку до установки панели привода
- * لا تقم بإزالة الغطاء قبل تركيب لوحة التشغيل *



PRO-D



1




2




3














4















5












COMMON













COMMON














COMMON

















COMMON
















COMMON














COMMON



COMMON



COMMON



the.artceram

ARTCERAM SRL

Headquarters

VIA MONSIGNOR TENDERINI SNC 01033 CIVITA CASTELLANA (VT) ITALY

T: +39 0761 599499

F: +39 0761 514232

e-mail: info@artceram.it

www.artceram.it