

# A16

*innovative solutions*

Vasi universali filo parete

1) Dopo aver predisposto gli scarichi secondo le quote riportate sulle schede tecniche, bloccare le due staffe alla parete seguendo le coordinate riportate nel disegno in Figura 2-3

2) Posizionare le staffe dietro il sanitario come da indicazioni della Figura 4

3) Posizionare la curva tecnica nella flangia a pavimento. Ancorare la piastra alla parete e collegare con la curva tramite perno filettato. Figura 5

4) Innestare il canotto di alimentazione tagliato a misura direttamente sul bocchettone della cassetta.

5) Per i vasi con scarico a parete Figura 6 posizionare il raccordo direttamente sulla flangia a parete. Posizionare la protezione ZIG-ZAG (che trovate nell'imballaggio) sulla parete posteriore del sanitario seguendo le istruzioni riportate sulla scatola.

6) Spingere il sanitario verso il muro facendo attenzione che i accordi si innestino ai canotti e muovere lateralmente il pezzo come da Figura 8 sino a quando il sanitario si aggancia alle staffe.

7) Per la rimozione alzare il sanitario sul davanti Figura 9.

## Back to wall WC

1) After having arranged the drains according to the technical drawings, fix the brackets to the wall following the dimensions in Figures 2-3.

2) Place the brackets behind the Wc as in Figure 4.

3) Fix the trap to the floor plate. Fix the plate to the wall and connect the trap by using the threaded screw as in Figure 5.

4) After cutting the feed pipe according to the right size, insert it directly to the union of the cistern.

5) For the wall-trap Wc - see Figure 6 - place the pipe directly to wall flange. Place the Zig-Zag (included in the box) at the back of the Wc following the instructions on the box.

6) Push the Wc to the wall paying attention that the pipes are inserted into the feed pipes and then move the Wc left and right as in Figure 8 until it gets fixed to the brackets.

7) For removing the Wc, lift up the front part of the WC as in Figure 9.

Artceram srl

Via Monsignor Tenderini snc - 01033 Civita Castellana (vt) - Italia  
tel. 0761.599499 r.a. - www.artceram.it - e-mail: info@artceram.it

